

Contact Details

Please note that some of the contact details on this PDF document may not be current.

Please use the following details if you need to contact us:

Telephone: 0844 879 3588

Email: customer.services@gdcgroup.co.uk

The customer support section of our website also features a wide range of information which may be of use to you and is available 24 hours a day. It includes:

- Operating and installation instructions
- Easy 'How to use' guides for storage heaters
- Service and repairs
- Where to buy our products
- Literature downloads
- Heating requirement calculator


Visit - www.dimplex.co.uk/support

Quick Start Guide


XMS Automatic Storage Heaters

This guide is for quick reference only. Refer to the XMS installation and operating instructions for further information

XMS Automatic Storage Heater



Control Options



Heater Controls

Automatic Input control - controls the temperature of the room

Adjust control for the first few days until your ideal room temperature is found, then leave on this setting. Heater will automatically adjust for changing weather.

Boost control - controls the amount of heat given later in the day

Normally leave boost setting at minimum. Turn up if more heat is required later in the day. Leaving the control on a higher setting will provide automatic boost each day.

On/Off Switch

Leave on for heating season.

