

Dimplex Oil filled Column Radiator

08/18843/0 Issue 0

Model : OF500

Model(s)	Specification
OF500	6 Fin, 500W, Thermostat, Mains Neon

THESE INSTRUCTIONS SHOULD BE READ CAREFULLY AND RETAINED FOR FUTURE REFERENCE.

IMPORTANT SAFETY ADVICE




Fig. 1

WARNING – THIS RADIATOR MUST ONLY BE OPERATED IN THE UPRIGHT POSITION WITH THE FOOT FITTED, AS DETAILED IN THE LEAFLET

This radiator complies with stringent safety standards but to ensure efficient operation **SURFACES OF THE RADIATOR WILL BECOME HOT AND CONTACT WITH THESE AREAS SHOULD BE AVOIDED**, particularly between the fins.

The control panel area is designed to be cooler and allow safe operation of the controls at all times.

If young children, the aged or infirm are likely to be left in the vicinity of the heater, we advise that adequate precautions should be taken. We recommend that a guard be fitted to ensure contact with the heater is avoided and objects cannot be inserted into the product.

WARNING – DO NOT USE THIS RADIATOR IN THE IMMEDIATE SURROUNDINGS OF A BATH, A SHOWER OR A SWIMMING POOL.

WARNING – THIS RADIATOR MUST NOT BE LOCATED IMMEDIATELY BELOW A FIXED SOCKET OUTLET.

This radiator must be used on an ~ supply only and the voltage marked on the heater must correspond with the supply voltage.

DO NOT USE the radiator if it has been dropped or damaged or the mains lead has been damaged, until it has been examined by a qualified engineer.

DO ENSURE that the mains lead cannot be tripped over.

DO NOT operate the radiator with the mains lead overhanging the fins.

DO NOT COVER THE RADIATOR or place material or garments on it or between the fins. Do not obstruct the air circulation around the radiator, for example with curtains or furniture, as this could cause overheating and a fire risk. See 'Positioning the Radiator'.

THIS RADIATOR CARRIES A WARNING 'DO NOT COVER' TO ALERT THE USER TO THE RISK OF FIRE THAT EXISTS IF THE RADIATOR IS ACCIDENTALLY COVERED.

DO NOT USE THIS RADIATOR WHEN IT IS LYING ON ITS SIDES. If the radiator is tipped over, unplug it and allow it to cool before standing it back up.

If the mains lead is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

The appliance is not intended for use by young children or infirmed persons without supervision.

Young children should be supervised to ensure they do not play with the appliance.


Electrical connections

WARNING – THIS APPLIANCE MUST BE EARTHED

This heater must be used on an AC ~ supply only and the voltage marked on the heater must correspond to the supply voltage. If fitting a 13 amp plug, a 13 amp fuse approved by ASTA to BS 1362 must be used. If any other type of plug is used, a 15 amp fuse must be fitted in the plug, the adaptor, or at the distribution board.

IMPORTANT - The wires in the mains lead are coloured in accordance with the following code:

GREEN and YELLOW	-	EARTH
BLUE	-	NEUTRAL
BROWN	-	LIVE

Connect the **GREEN AND YELLOW** wire to the terminal marked 'E' or by the earth symbol, or  coloured **GREEN** or **GREEN AND YELLOW**.

Connect the **BROWN** wire to the terminal marked 'L' or coloured **RED**.

Connect the **BLUE** wire to the terminal marked 'N' or coloured **BLACK**.

This appliance must only be used on A.C. mains supply of 230-240 Volts~.

Positioning the radiator

Always ensure that the radiator is stood on a firm, level base near to, but not directly beneath, a suitable fixed socket outlet.

Unwind the mains lead fully before plugging in the radiator. DO NOT pull the radiator along by the mains lead.

Ensure that curtains and furniture are not closer than 1 metre (3') from the chosen position, as this would create a potential fire hazard.

Ensure that there is at least 300mm (1') above the radiator of unobstructed space.

Before switching on

Ensure that all packing items are removed (read any warning labels carefully) and that all warnings and instructions have been read carefully and followed.

Fitting the foot




Fig. 2

The rear foot (see Fig. 2) is not permanently attached to the heater and clips over the end fin. The heater should never be used without the rear foot in its correct position.

When unpacking the heater the rear foot should be in position i.e. attached to the end fin. In the event that the rear foot has fallen off in transit, turn the radiator upside down on a carpet or other soft surface to avoid damage, and clip the foot into position on to the bottom of the end fin - see Fig. 2.





Fig. 3

IMPORTANT – ENSURE THAT THE FOOT IS FITTED TO THE BASE OF THE RADIATOR SO THAT, WHEN IN USE, THE HANDLE IS AT THE TOP OF THE CONTROL PANEL – see Fig. 3.

Operation



Thermostat knob - Fig. 4

When you are certain that you have completed the above, plug in and switch on at the wall socket. The neon will glow all the time that the radiator is connected to the power supply.

Please Note – We recommend that you open a window to ventilate the room when using the heater for the first time.

Thermostat control (see Fig. 4)

The heat output is controlled by the thermostat, according to the room temperature.

Turn the knob to **max.** setting. When the room is warm enough, reduce the setting slowly until the radiator just clicks off.

The radiator will now cycle on and off to maintain your selected room temperature.

NOTE : If the radiator does not come on when the thermostat is on a low setting, this is normally because the room is warmer than the thermostat setting and is not a fault.

If the thermostat is set to **min.** the thermostat will turn the radiator on and off to maintain a low temperature to help protect against frosty conditions.

Storage

If the radiator is not required for long periods, for example during the summer, it should be stored in dry place and preferably covered to prevent the accumulation of dust and dirt.

Cleaning

WARNING – ALWAYS DISCONNECT FROM THE POWER SUPPLY AND ALLOW THE RADIATOR TO COOL BEFORE CLEANING.

Do not use detergents, abrasive cleaning powder or polish of any kind on the body of the radiator, as these can damage the finish.

Wipe the radiator with a dry cloth to remove dust and a damp cloth (not wet) to clean off stains. Be careful not to allow moisture into the controls area.

After Sales Service

Your appliance is guaranteed for three years from the date of purchase. We undertake to repair or exchange free of charge within this period, any part found to be defective due to a manufacturing fault.

This heater is filled with a precise quantity of special oil. Repairs requiring opening of the oil container are only to be made by the manufacturer or its service agent who should be contacted if there is an oil leakage.

Regulations concerning the disposal of oil when scrapping the appliance have to be followed.

Your rights under this guarantee are additional to your statutory rights, which in turn are not affected by this guarantee.

Please retain your receipt as proof of purchase.



The product complies with the European Safety Standards EN60335-2-30 and the European Standard Electromagnetic Compatibility (EMC) EN55014, EN60555-2 and EN60555-3 which cover the essential requirements of EEC Directives 73/23 and 89/336

Glen Dimplex UK Limited
Millbrook House
Grange Drive
Hedge End
Southampton
Hampshire. SO30 2DF

UK customer help line (8.00AM – 6.00PM Mon-Fri; 8.30AM-1.00PM Sat)

Customer Services: Tel. 0870 7270101
Fax. 0870 7270102
e-mail customer.services@glendimplex.com
Republic of Ireland Tel. 01 8424833